

PARAMOTORE SPECIFICO - SPECIFIC ENGINE GUARD - PARE-CARTER SPECIFIQUE  
 SPEZIFISCHES STURZBUEGEL - PROTEGEMOTOR ESPECIFICO

# SUZUKI GSX750 '98/'01

ISTRUZIONI DI MONTAGGIO - MOUNTING INSTRUCTIONS  
 INSTRUCTIONS DE MONTAGE - BAUANLEITUNG - INSTRUCCIONES DE MONTAJE

①



**PARAMOTORE**  
 ENGINE GUARD  
 PARE CARTER

**Q.TY n.2**

②



**DISTANZIALE**  
 Ø 14X14  
 COLLAR DISTANCE  
 ENTRETOISE

**Q.TY n.2**

③



**DISTANZIALE**  
 Ø 14X8  
 COLLAR DISTANCE  
 ENTRETOISE

**Q.TY n.2**

④



**RONDELLA Ø 8**  
 WASHER Ø 8  
 RONDELLE Ø 8

**Q.TY n.4**

⑤



**VITE TE M 8 X 65**  
 SCREW M 8 X 65

**Q.TY n.4**

⑥



**VITE ORIGINALE**  
 ORIGINAL SCREW  
 VIS ORIGINAL

**Q.TY n.-**

⑦



**VITE TE M 10 X 55**  
 PASSO 1,25  
 SCREW M 10 X 55  
 VIS M 10 X 55

**Q.TY n.1**

